

INSTRUCTION MANUAL

SIL 2 Multifunction Sink-Out Temperature Converter DIN-Rail and Termination Board Models D6072S-099, D6072D-099



Characteristics

General Description: The single and dual channel Temperature Signal Converter D6072S-099 and D6072D-099 accepts a low level dc signal from millivolt, thermocouple or resistance/ RTD or transmitting potentiometer sensor and converts, with isolation, the signal to drive a load, suitable for applications requiring SIL 2 (according to IEC 61508:2010) in safety related systems for high risk industries. Output signal can be direct or reverse. Modbus RTU RS-485 output is available on Bus connector. Cold junction compensation can be programmed as:

- Automatic: provided by an internal temperature sensor;
- Fixed: to a user-customizable temperature value;
- External: making use of an external RTD;
- Remote: (only D6072D-099) connecting compensation RTD to one of the two channels.

For D6072D-099 module: duplicator function provides two independent outputs from one single input. Output function can be configured as: average, subtractor, low/high or redundancy selector. Modules are provided with alarm function, which is available via solid state contact output, Termination Board and Power Bus. Mounting on standard DIN-Rail, with or without Power Bus, or on customized Termination Boards, in Safe Area / Non Hazardous Location or in Zone 2 / Class I, Division 2.

Functional Safety Management Certification:

G.M. International is certified by TUV to conform to IEC61508:2010 part 1 clauses 5-6 for safety related systems up to and included SIL3

Technical Data

Supply: 24 Vdc nom (18 to 30 Vdc) reverse polarity protected, ripple within voltage limits ≤ 5 Vpp, 2 A time lag fuse internally protected.

Current consumption @ 24 V: 50 mA (D6072D-099), 42 mA (D6072S-099) with 20 mA out typical. Power dissipation @ 24 V: 1.0 W (D6072D-099), 0.9 W (D6072S-099) with 20 mA out typical

Isolation (Test Voltage): I.S. In/Out 2.5 KV; I.S. In/Supply 2.5 KV; I.S. In/I.S. In 500 V; Out/Supply 500 V; Out/Out 500 V.

Input: See section "Input specifications" for more details on Input sensors.

4-wire RTD input only on D6072S-099. Possibility of configuring user customized sensor (TC or RTD). Choice between °C/°F.

Integration time: from 50 ms to 500 ms depending on sensor and fast/slow integration. **Resolution:** 1 μ V on mV/TC, 1 m Ω on RTD/resistance, 0.0001 % on transmitting pot. Visualization: 0.1 °C on temp.,10 μV on mV, 10 m Ω on resistance, 0.1 % on pot. Input range: within sensor limits (-500 to +500 mV for mV, 0-4 k Ω for resistance).

Measuring RTD current: ≤ 0.15 mA.

2 wire RTD line resistance compensation: $\leq 50 \Omega$ (programmable).

Thermocouple Reference Junction Compensation: programmable as automatic with internal compensator, fixed (-60 to +100 °C), external with any supported RTD, or remote using 1 channel (D6072D-099).

Thermocouple burnout current: ≤ 50 µA.

Fault: enabled or disabled. Analog output can be programmed to reflect fault conditions via downscale, highscale or customized value forcing. Fault conditions are also signaled via BUS and by red LED on front panel for each channel. Fault conditions are: Sensor burnout, Sensor out of range, Output saturation, Internal fault, Cable resistance fault.

Output: Fully customizable 0/4 to 20 mA (sink mode), current limited at 24 mA. External voltage generator range is V min. 3.5V at 0Ω load and V max. 30V.

If generator voltage Vg > 10 V, a series resistance ≥ (Vg - 10)/0.024 Ω is needed. The maximum value of series resistance is (Vg - 3.5)/0.024 Ω.

Resolution: 1 µA current output.

Transfer characteristic: linear, direct or reverse on all input sensors.

Response time: \leq 20 ms (10 to 90 % step). Output ripple: \leq 20 mVrms on 250 Ω load. Damping factor: ≤ 30 s, configurable.

Modbus Output: Modbus RTU protocol, from 4800 to 115.200 bps.

Alarm: Trip point range: within rated limits of input sensor (see input step resolution).

ON-OFF delay time: 0 to 1000 s, 100 ms step. Hysteresis: within rated limits of input sensor.

Output: voltage free SPST photoMOS: 100 mA, 60 Vdc (≤ 1 V voltage drop).

Performance: Ref. Conditions 24 V supply, 250 Ω load, 23 ± 1 °C ambient temperature, slow integration mode, 4-wires (for D6072S-099) or 3-wires (for D6072D-099) configuration for RTD.

Input: Calibration and linearity accuracy: see section "Input Specifications".

Temperature influence: see section "Input Specifications".

Ref. Junction Compensation influence: ≤ ± 1 °C (internal PT1000 sensor).

Analog Output: Calibration accuracy: ≤ ±10 µA.

Linearity error: ≤ ±10 µA.

Supply voltage influence: $\leq \pm 0.02$ % of full scale for a min to max supply change. Load influence: ≤ ±0.02 % of full scale for a 0 to 100 % load resistance change.

Temperature influence: ≤ ±2 µA/°C.

Compatibility:

CE mark compliant, conforms to Directive: 2014/34/EU ATEX, 2014/30/EU EMC, 2014/35/EU LVD, 2011/65/EU RoHS.

Environmental conditions:

Operating: temperature limits - 40 to + 70 °C, relative humidity 95 %, up to 55 °C.

Max altitude: 2000 m a.s.l.

Storage: temperature limits - 45 to + 80 °C.

Safety Description:











ATEX: II 3G Ex ec IIC T4 Gc; IECEx: Ex ec IIC T4 Gc UL: NI / I / 2 / ABCD / T4; C-UL: NI / I / 2 / ABCD / T4

EAC-EX: 2Ex ec IIC T4 Gc X

Approvals:

BVS 20 ATEX E 059 X conforms to EN60079-0, EN60079-7; IECEx BVS 20.0047X conforms to IEC60079-0, IEC60079-7.

UL & C-UL E222308 conforms to UL 61010-1 and UL 121201 for UL and CAN/CSA C22.2 No.61010-1-12 and CSA C22.2 No. 213 for C-UL.

EAGC RU C-IT.AA87.B.00796/21 conforms to GOST 31610.0, GOST 31610.7.

TÜV Certificate No. C-IS-722160171, SIL 2 conforms to IEC61508:2010 Ed.2 .

SIL 3 Functional Safety TÜV Certificate conforms to IEC61508:2010 Ed.2, for Management of Functional Safety.

Mounting: EN/IEC60715 TH 35 DIN-Rail, with or without Power Bus or on customized Termination Board.

Weight: about 135 g D6072D-099, 130 g D6072S-099.

Connection: by polarized plug-in disconnect screw terminal blocks to accommodate terminations up to 2.5 mm².

Location: installation in Safe Area/Non Hazardous Locations or Zone 2, Group IIC T4 or Class I, Division 2, Group A,B,C,D, T4.

Protection class: IP 20.

Dimensions: Width 12.5 mm, Depth 123 mm, Height 120 mm.

Programming

The module is fully programmable. Operating parameters can be changed from PC via PPC5092 adapter connected to USB serial line and SWC5090 software. Measured values and diagnostic alarms can be read on both serial configuration or Modbus output line.

SWC5090 software also allows the Monitoring and Recording of values. For details please see SWC5090 manual ISM0154.

Ordering Information

Model:	D6072		-099
1 channel		S	
2 channels		D	

Power Bus and DIN-Rail accessories: Connector JDFT049 Terminal block male MOR017

Cover and fix MCHP196
Terminal block female MOR022

Front Panel and Features











27 Ø 8 29 Ø1 211 Ø1

- SIL 2 according to IEC 61508:2010 (Route 2H) with Tproof = 10 / 20 years (≤10% / >10 % of total SIF), for analog current sink output.
- SIL 2 according to IEC 61508:2010 (Route 2H) with Tproof = 9 / 20 years (≤10% / >10 % of total SIF), for alarm output.
- SC 3: Systematic Capability SIL 3.
- Installation in Zone 2 / Division 2.
- mV, thermocouple, 2 or 3 or 4 wire resistance/RTD or transmitting potentiometer Input Signal.
- 2-wire RTD line resistance compensation.
- Internal Reference Junction Compensation.
- Fastest integration time: 50 ms
- Fully customizable Output range from 0 to 24 mA Output Signal linear or reverse (typical 0/4-20 mA).
- Output duplication possible for D6072D-099.
- Modbus RTU RS-485 Output.
- Independent multiple Fault detection.
- Programmable alarm available on solid state contact output or Termination Board connector.
- High Accuracy, µP controlled A/D converter.
- Three port isolation, Input/Output/Supply.
- EMC Compatibility to EN61000-6-2, EN61000-6-4, EN61326-1, EN61326-3-1 for safety system.
- Fully programmable operating parameters.
- ATEX, IECEx, UL & C-UL, EAC-EX, TÜV Certifications.
- TÜV Functional Safety Certification.
- High Density, two channels per unit.
- Simplified installation using standard DIN-Rail and plug-in terminal blocks, with or without Power Bus, or customized Termination Boards.
- Data logging and monitoring via software.

Terminal block connections







- D6072S-099: +Input for thermocouple TC or for 3, 4 wire RTD or potentiometer 7 D6072D-099: +Input Ch1 for thermocouple TC or for 3 wire RTD or potentiometer D6072S-099: -Input for thermocouple TC or for 2, 3, 4 wire RTD or potentiometer 8 D6072D-099: -Input Ch1 for thermocouple TC or for 2, 3 wire RTD or potentiometer D6072S-099: Input for 2, 3, 4 wire RTD or potentiometer 9 D6072D-099: Input Ch1 for 2, 3 wire RTD or potentiometer D6072S-099: Input for 4 wire RTD 10 D6072D-099: Input Ch2 for 2, 3 wire RTD or potentiometer D6072D-099: +Input Ch2 for thermocouple TC or for 3 wire RTD 11 or potentiometer D6072D-099: -Input Ch2 for thermocouple TC or for 2, 3 wire RTD
- 1 +Output Ch1 (sink current mode)
- 2 -Output Ch1 (sink current mode)
- 3 D6072S-099 (Alarm), D6072D-099 (Current/Alarm):
 +Output Ch2 (sink current) or +Output (Alarm/Fault)
- 4 D6072S-099 (Alarm), D6072D-099 (Current/Alarm):
 -Output Ch2 (sink current) or -Output (Alarm/Fault)
- 5 +Power Supply 24 Vdc
- 6 -Power Supply 24 Vdc

or potentiometer

12


SAFE AREA, ZONE 2 GROUP IIC T4, NON HAZARDOUS LOCATIONS, CLASS I, DIVISION 2, GROUPS A, B, C, D T-Code T4







Function Diagram

SAFE AREA, ZONE 2 GROUP IIC T4, NON HAZARDOUS LOCATIONS, CLASS I, DIVISION 2, GROUPS A, B, C, D T-Code T4







Warning

D6072-099 series are isolated apparatus installed into standard EN/IEC60715 TH 35 DIN-Rail located in Safe Area/Non Hazardous Locations or Zone 2, Group IIC T4 or Class I, Division 2, Group A, B, C, D, T4 Hazardous Area within the specified operating temperature limits Tamb -40 to +70 °C.

D6072-099 series must be installed, operated and maintained only by qualified personnel, in accordance to the relevant national/international installation standards (e.g. EN/ IEC60079-14 Electrical apparatus for explosive gas atmospheres - Part 14: Electrical installations in hazardous areas (other than mines)), following the established installation rules. De-energize power source (turn off power supply voltage) before plug or unplug the terminal blocks when installed in Hazardous Area or unless area is known to be nonhazardous.

Warning: substitution of components may impair suitability for Zone 2/ Division 2. Avertissement: la substitution des composants peut nuire à l'aptitude à la Zone 2/Div. 2. Explosion Hazard: to prevent ignition of flammable atmospheres, disconnect power before servicing or unless area is known to be nonhazardous. Danger d'Explosion: pour éviter l'inflammation d'atmosphères inflammables, débrancher l'alimentation avant l'entretien ou à moins que région est connue pour être non dangereuse.

Failure to properly installation or use of the equipment may risk to damage the unit or severe personal injury.

The unit cannot be repaired by the end user and must be returned to the manufacturer or his authorized representative. Any unauthorized modification must be avoided.

Operation

Each input channel of Temperature Signal Converter D6072-099 accepts a low level dc signal from millivolt, thermocouple or 2-3-4 wire RTD temperature or transmitting potentiometer sensor and converts, with isolation, the signal to a 4-20 mA floating output current to drive a load.

Presence of supply power is displayed by a "POWER ON" green signaling LED; integrity of field sensor and connecting line can be monitored by a configurable burnout circuit which, if enabled, can drive output signal to upscale or downscale limit. Burnout condition is signaled by red front panel LED for each channel.

D6072D-099 module has double input and output channel, and can also be programmed to interface a single input and obtain dual output channel (duplicator) or configurable output channel (outputs can repeat the corresponding inputs or be proportional to the sum or difference of the two input process variables or with low/high selector function).

Installation

D6072-099 series are Temperature Signal Converter housed in a plastic enclosure suitable for installation on EN/IEC60715 TH 35 DIN-Rail, with or without Power Bus or on customized Termination Board.

D6072-099 series can be mounted with any orientation over the entire ambient temperature range.

Electrical connection are accommodated by polarized plug-in removable screw terminal blocks which can be plugged in/out into a powered unit without suffering or causing any damage (for Zone 2 installations check the area to be nonhazardous before servicing). Connect only one individual conductor per each clamping point, use conductors up to 2.5 mm² (13 AWG) and a torque value of 0.5-0.6 Nm. Use only cables that are suitable for a temperature of at least 85°C. The wiring cables have to be proportionate in base to the current and the length of the cable.

In case of installation in zone 2, the connecting cables of non-intrinsically safe circuits must be safely routed in a cable duct or similar. The distance between the pluggable connection terminal and the cable duct should not exceed 500 mm cable length.

On the section "Function Diagram" and enclosure side a block diagram identifies all connections.

Connect alarm transistors checking the load rating to be within the maximum rating (100 mA at 60 Vdc (≤ 1 V voltage drop)).

The enclosure provides, according to EN60529, an IP20 minimum degree of protection. The equipment shall only be used in an area of at least pollution degree 2, as defined in IEC 60664-1. When installed in EU Zone 2, the unit shall be installed in an enclosure that provides a minimum ingress protection of IP54 in accordance with IEC 60079-0. When installed in a Class I, Division 2 Hazardous Location, the unit shall be mounted in a supplemental enclosure that provides a degree of protection not less than IP54. The enclosure must have a door or cover accessible only by the use of a tool. The end user is responsible to ensure that the operating temperature of the module is not exceeded in the end use application. Units must be protected against dirt, dust, extreme mechanical (e.g. vibration, impact and shock) and thermal stress, and casual contacts. If enclosure needs to be cleaned use only a cloth lightly moistened by a mixture of detergent in water.

Electrostatic Hazard: to avoid electrostatic hazard, the enclosure of D6072-099 must be cleaned only with a damp or antistatic cloth.

Any penetration of cleaning liquid must be avoided to prevent damage to the unit. Any unauthorized modification must be avoided.

D6072-099 series must be connected to SELV or PELV supplies.

All circuits connected to D6072-099 series must comply with the overvoltage category II (or better) according to EN/IEC60664-1.

Start-up

Before powering the unit check that all wires are properly connected, particularly supply conductors and their polarity, input and output wires.

Check conductors for exposed wires that could touch each other causing dangerous unwanted shorts.

Check that the module has been correctly configured through SWC5090 software. For details please see SWC5090 manual ISM0154.

Turn on power, the "power on" green LED must be lit, output on each channel must be in accordance with the corresponding input signal value and input/output chosen transfer function. If possible change the sensor condition and check the corresponding output.

Input specifications:

Input	Туре	Alpha [°C-1]	Nominal resistance [Ω]	Standards	Min Span [°C (°F)]	Accuracy [°C (°F)]	Accuracy Range [°C (°F)]	Maximum Range [°C (°F)]	Temperature Influence per °C typical [°C (°F)]
		0.003851	50 100 200 300 400 500	IEC 60751 GOST 6651 JIS C 1604	40 (72) 20 (36) 10 (18)	±0.5 (±0.9) ±0.2 (±0.4) ±0.1 (±0.2)	-200 to 850 (-328 to 1562)	-200 to 850 (-328 to 1562)	≤ ±0.015 (≤ ±0.027)
		0.003916	1000	JIS C 1604	20 (36)	±0.2 (±0.4)	-200 to 630 (-328 to 1166)	-200 to 630 (-328 to 1166)	≤ ±0.015 (≤ ±0.027)
	Platinum	0.003926	100		20 (36)	±0.2 (±0.4)	-200 to 630 (-328 to 1166)	-200 to 630 (-328 to 1166)	≤ ±0.027) ≤ ±0.015 (≤ ±0.027)
			46 50		40 (72)	±0.5 (±0.9)	(-320 to 1100)	(-320 to 1100)	(= ±0.021)
RTD		0.003911	100 200 300 400 500	GOST 6651	20 (36)	±0.2 (±0.4) ±0.1 (±0.2)	-200 to 650 (-328 to 1202)	-200 to 650 (-328 to 1202)	≤ ±0.015 (≤ ±0.027)
		0.006178	100	DIN 43760	/	±0.2 (±0.4)	-60 to 180 (-76 to 356)	-60 to 180 (-76 to 356)	≤ ±0.015 (≤ ±0.027)
	Nickel	0.006720	120		20 (36)	±0.2 (±0.4)	-80 to 260 (-112 to 500)	-80 to 260 (-112 to 500)	≤ ±0.015 (≤ ±0.027)
		0.004260	53	GOST 6651	40 (72)	±0.4 (±0.7)	-50 to 180 (-58 to 356)	-50 to 180 (-58 to 356)	≤ ±0.015 (≤ ±0.027)
	Copper	0.004280	50 100	GOST 6651	40 (72) 20 (36)	±0.4 (±0.7) ±0.2 (±0.4)	-50 to 200 (-58 to 392)	-50 to 200 (-58 to 392)	≤ ±0.015 (≤ ±0.027)
		0.004274	9.035		100 (180)	±1.7 (±3.1)	-200 to 260 (-328 to 500)	-200 to 260 (-328 to 500)	≤ ±0.050 (≤ ±0.090)
	P	11		GOST 8.585	150 (270)	±0.7 (±1.3)	0 to 2500 (32 to 4532)	0 to 2500 (32 to 4532)	≤ ±0.090 (≤ ±0.162)
	A	\2		GOST 8.585	100 (180)	±0.5 (±0.9)	0 to 1800 (32 to 3272)	0 to 1800 (32 to 3272)	≤ ±0.050 (≤ ±0.090)
	А3			GOST 8.585	100 (180)	±0.5 (±0.9)	0 to 1800 (32 to 3272)	0 to 1800 (32 to 3272)	≤ ±0.050 (≤ ±0.090)
		В		IEC 60584 GOST 8.585 ASTM E230	200 (360)	±1.1 (±2.0)	450 to 1820 (842 to 3308)	0 to 1820 (32 to 3308)	≤ ±0.060 (≤ ±0.108)
	С			ASTM E230 ASTM E988	100 (180)	±0.6 (±1.1)	0 to 2315 (32 to 4199)	0 to 2315 (32 to 4199)	≤ ±0.080 (≤ ±0.144)
	1	D		ASTM E988	100 (180)	±0.6 (±1.1)	0 to 2315 (32 to 4199)	0 to 2315 (32 to 4199)	≤ ±0.080 (≤ ±0.144)
	E			IEC 60584 GOST 8.585 ASTM E230	50 (90)	±0.2 (±0.4)	-150 to 1000 (-238 to 1832)	-270 to 1000 (-454 to 1832)	≤ ±0.050 (≤ ±0.090)
	J			IEC 60584 GOST 8.585 ASTM E230	50 (90)	±0.2 (±0.4)	-150 to 1200 (-238 to 2192)	-210 to 1200 (-346 to 2192)	≤ ±0.050 (≤ ±0.090)
TC	l	K		IEC 60584 GOST 8.585 ASTM E230	50 (90)	±0.3 (±0.5)	-150 to 1372 (-238 to 2502)	-270 to 1372 (-454 to 2502)	$\leq \pm 0.050$ ($\leq \pm 0.090$)
	L (type	"L" DIN)		DIN 43710	50 (90)	±0.2 (±0.4)	-200 to 900 (-328 to 1652)	-200 to 900 (-328 to 1652)	≤ ±0.050 (≤ ±0.090)
	LR (type	"L" GOST)		GOST 8.585	50 (90)	±0.3 (±0.5)	-200 to 800 (-328 to 1472)	-200 to 800 (-328 to 1472)	≤ ±0.050 (≤ ±0.090)
	N			IEC 60584 GOST 8.585 ASTM E230	50 (90)	±0.4 (±0.7)	-150 to 1300 (-238 to 2372)	-270 to 1300 (-454 to 2372)	≤ ±0.060 (≤ ±0.108)
	R			IEC 60584 GOST 8.585 ASTM E230	150 (270)	±0.8 (±1.4)	50 to 1768 (122 to 3214)	-50 to 1768 (-58 to 3214)	≤ ±0.060 (≤ ±0.108)
	S			IEC 60584 GOST 8.585 ASTM E230	150 (270)	±0.8 (±1.4)	50 to 1768 (122 to 3214)	-50 to 1768 (-58 to 3214)	≤ ±0.060 (≤ ±0.108)
		Т		IEC 60584 GOST 8.585 ASTM E230	50 (90)	±0.2 (±0.4)	-100 to 400 (-148 to 752)	-270 to 400 (-454 to 752)	≤ ±0.020 (≤ ±0.036)
	ı	J		DIN 43710	50 (90)	±0.4 (±0.7)	-200 to 600 (-328 to 1112)	-200 to 600 (-328 to 1112)	≤ ±0.040 (≤ ±0.072)
		rpe	Nominal resistance [Ω]		Min Span [Ω]	Accuracy [Ω]	Accuracy Range [Ω]	Maximum Range [Ω]	Temperature Influence per °C typical [Ω]
Ohm		e standard e extended	0 to 1000 0 to 4000		5 20	±0.2 ±0.4	0 to 1000 0 to 4000	0 to 1000 0 to 4000	≤ ±0.02 ≤ ±0.20
		iometer	100 to 10000		1%	±0.1%	0 to 100%	0 to 100%	≤ ±0.02%
		ре			Min Span [mV]	Accuracy [µV]	Accuracy Range [mV]	Maximum Range [mV]	Temperature Influence per °C typical [µV]
mV		andard tended			1 10	±10 ±100	-50 to 80 -500 to 500	-100 to 100 -500 to 500	≤ ±3 ≤ ±20
	200%								

Notes:RTD/resistance accuracy shown in 4-wires (for D6072S-099) or 3-wires (for D6072D-099) configuration, in slow acquisition mode, after calibration.
TC/mV Accuracy shown in slow acquisition mode, after calibration.

Supported Modbus functions:

Code	Name	Notes		
03	read holding registers	reads a stream of words from memory		
04	read input registers	reads a stream of words from memory		
08	diagnostics: subcode 0	returns query data		
06	write single register	writes a word in memory		
16	write multiple registers	writes a stream of words in memory		

Supported Modbus parameters:

The unit can communicate via Modbus RTU RS-485 protocol. Below is a list of all available registers.

Each Modbus parameter is described by one 16-bit word.

- 'Addr.' is the address of the parameter.
- 'Description' explains the function of the parameter.
- 'Rights' identifies the operation that can be executed by the user: RO (Read Only);

WO (Write Only);

RW (Read and Write).

- 'Type' indicates the kind of the variable:

SINT8 / UINT8: signed / unsigned 8 bits integer;

SINT16 / UINT16: signed / unsigned 16 bits integer;

SINT32 / UINT32: signed / unsigned 32 bits integer; FLOAT: floating point single precision real;

DOUBLE: floating point double precision real;

the suffix '[n]' indicates an array of n elements of the corresponding type.

Addr.	Description	Rights	Туре
IDENTIF	ICATION		
0	GM International code	RO	UINT16
1	Software revision	RO	UINT16
2	Product code	RO	UINT16
3	Option code	RO	UINT16
4	Hardware revision	RO	UINT16
COMMA	ND EXECUTION		
100	Command (*1)	WO	UINT16
GENER/	AL CONFIGURATION		
202	Fault on bus mask (*2)	RW	UINT32
MODBU	S COMMUNICATION (
300	Modbus address	RW	UINT16
301	Modbus baud-rate (*3)	RW	UINT16
302	Modbus format (*4)	RW	UINT16
	AL DEBUG		0
400	Time stamp [100ms]	RO	UINT32
404	Cumulative faults (*2)	RO	UINT32
TAG	Samulativo Iddito (2)	110	0111102
700	Tag 1	RW	UINT8[16]
708	Tag 2	RW	UINT8[16]
	T CONFIGURATION	LVV	Olivio[10]
800	Input to analog out 1 function (*5)	RW	UINT16
			<u> </u>
801	Input to analog out 2 function (*5) CONFIGURATION	RW	UINT16
		DW	LUNITAC
803	Input to alarm 2 function (*5)	RW	UINT16
	CONFIGURATION	DW	LUNITAG
804	Integration speed (*6)	RW	UINT16
900	Ch1: sensor family (*7)	RW	UINT16
901	Ch1: sensor connection (*8)	RW	UINT16
902	Ch1: sensor type (*9)	RW	UINT16
903	Ch1: sensor burnout configuration (*10)	RW	UINT16
904	Ch1: cold junction compensation (*11)	RW	UINT16
905	Ch1: cold junction external type (*9)	RW	UINT16
1000	Ch2: sensor family (*7)	RW	UINT16
1001	Ch2: sensor connection (*8)	RW	UINT16
1002	Ch2: sensor type (*9)	RW	UINT16
1003	Ch2: sensor burnout configuration (*10)	RW	UINT16
1004	Ch2: cold junction compensation (*11)	RW	UINT16
1005	Ch2: cold junction external type (*9)	RW	UINT16
1100	Ch1: cold junction fixed value [0.1°C]	RW	SINT32
1102	Ch1: 2-wire rtd correction [mOhm]	RW	SINT32
1104	Ch1: rtd multiplier	RW	FLOAT
1200	Ch2: cold junction fixed value [0.1°C]	RW	SINT32
1202	Ch2: 2-wire rtd correction [mOhm]	RW	SINT32
1204	Ch2: rtd multiplier	RW	FLOAT
MEASU			1
1500	Ch1: sensor value (volt, res, ratio) [uV, mOhm, ppm]	RO	SINT32
1502	Ch1: cold junction resistance value [mOhm]	RO	SINT32
1504	Ch1: sensor temperature [0.1°C]	RO	SINT32
1504	Ch1: cold junction temperature [0.1°C]	RO	SINT32
	on a solu junicuon tomperature [c. r. oj	110	U11102

Addr.	Description	Rights	Туре
1602	Ch2: cold junction resistance value [mOhm]	RO	SINT32
1604	Ch2: sensor temperature [0.1°C]	RO	SINT32
1606	Ch2: cold junction temperature [0.1°C]	RO	SINT32
	CONFIGURATION		
1900	Ch1: output downscale [100nA]	RW	SINT32
1902	Ch1: output upscale [100nA]	RW	SINT32
1904	Ch1: output underrange [100nA]	RW	SINT32
1906	Ch1: output overrange [100nA]	RW	SINT32
1908	Ch1: output in case of fault [100nA]	RW	SINT32
1910	Ch1: output fault mask (*2)	RW	UINT32
1916	Ch1: output damping factor [s]	RW	UINT32
1918	Ch1: input downscale [uV, mOhm, ppm]	RW	SINT32
1920	Ch1: input upscale [uV, mOhm, ppm]	RW	SINT32
2000	Ch2: output downscale [100nA]	RW	SINT32
2002	Ch2: output upscale [100nA]	RW	SINT32
2004	Ch2: output underrange [100nA]	RW	SINT32
2004	Ch2: output overrange [100nA]	RW	SINT32
2008	Ch2: output in case of fault [100nA]	RW	SINT32
2010	Ch2: output fault mask (*2)	RW	UINT32
2016	Ch2: output damping factor [s]	RW	UINT32
2018	Ch2: input downscale [uV, mOhm, ppm]	RW	SINT32
2010	Ch2: input downscale [uV, mOnin, ppin]	RW	SINT32
	DEBUG	LVV	SINTOZ
2302		RO	SINT32
	Ch1: output virtual value [100nA]	RO	SINT32
2402	Ch2: output virtual value [100nA] CONFIGURATION	RU	3111132
		DW	UINT32
2600 2604	Ch2: alarm configuration (*13)	RW RW	UINT32
	Ch2: alarm start lock (*14)	RW	
2606	Ch2: contact position in case of alarm (*15)		UINT32
2608	Ch2: alarm fault configuration (*16)	RW	UINT32
2610	Ch2: alarm fault mask (*2)	RW	UINT32
2612	Ch2: delay to alarm issue [ms]	RW	UINT32
2614	Ch2: delay to alarm removal [ms]	RW	UINT32
2616	Ch2: alarm low threshold [uV, mOhm, ppm]	RW	SINT32
2618	Ch2: alarm low threshold hysteresis [uV, mOhm, ppm]	RW	SINT32
2620	Ch2: alarm high threshold [uV, mOhm, ppm]	RW	SINT32
2622	Ch2: alarm high threshold hysteresis [uV, mOhm, ppm]	RW	SINT32
ALARM		l	1
2806	Ch2: alarm virtual state (*17)	RO	UINT32
	ONFIGURATION	110	0
3100	Callendar-van dusen coeff. A [1/°C]	RW	FLOAT
3102	Callendar-van dusen coeff. B [1/°C2]	RW	FLOAT
3104	Callendar-van dusen coeff. C [1/°C4]	RW	FLOAT
3106	Callendar-van dusen res. at 0°C [mOhm]	RW	UINT32
3108	Table minimum temperature [0.1°C]	RW	SINT32
3110	Table maximum temperature [0.1°C]	RW	SINT32
3200	Sensor family (*7)	RW	UINT32
3202	Table minimum temperature [0.1°C]	RW	SINT32
3202	Table maximum temperature [0.1°C]	RW	SINT32
3206	Table temperature step [0.1°C]	RW	UINT32
3210	Custom sensor table [uV, mOhm]	RW	SINT32[100]

1 Command List		ters details:		5 6	thermocouple D thermocouple E
N'4 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	D	·		7	thermocouple J
Sit pos. Value	Descript 10	full eeprom write		8	thermocouple K
2 Fault Mask	10	Tuli copioni wine		9	thermocouple L
2 rauit wask Bit pos.	Value	Description		10 11	thermocouple LR
)0	0	no internal/hardware fault		12	thermocouple N thermocouple R
	1	internal/hardware fault		13	thermocouple S
l1	0	no configuration fault		14	thermocouple T
22	1 0	configuration fault no input 1 open/burnout		15	thermocouple U
22	1	input 1 open/burnout		16 17	Pt50 rtd (a=0.003851) Pt100 rtd (a=0.003851)
33	Ö	no input 2 open/burnout		18	Pt200 rtd (a=0.003851)
	1	input 2 open/burnout		19	Pt300 rtd (a=0.003851)
14	0	no input 1 cold junction		20	Pt400 rtd (a=0.003851)
	1	input 1 cold junction		21	Pt500 rtd (a=0.003851)
55	0 1	no input 2 cold junction input 2 cold junction		22	Pt1000 rtd (a=0.003851)
56	Ó	no input 1 cable resistance		23 24	Pt46 rtd (a=0.003911) Pt50 rtd (a=0.003911)
, .	1	input 1 cable resistance		25	Pt100 rtd (a=0.003911)
' 7	0	no input 2 cable resistance		26	Pt200 rtd (a=0.003911)
	1	input 2 cable resistance		27	Pt300 rtd (a=0.003911)
38	0	no input 1 out of spec		28	Pt400 rtd (a=0.003911)
	1	input 1 out of spec		29	Pt500 rtd (a=0.003911)
99	0 1	no input 2 out of spec input 2 out of spec		30	Pt100 rtd (a=0.003916)
1010	0	no analog out 1 saturation		31	Pt100 rtd (a=0.003926)
	1	analog out 1 saturation		32 33	Cu53 rtd (a=0.004260) Cu9.035 rtd (a=0.004274)
111	Ö	no analog out 2 saturation		აა 34	Cu50 rtd (a=0.004274)
	1	analog out 2 saturation		35	Cu100 rtd (a=0.004280)
3 Modbus Baudra	ite			36	Ni100 rtd (a=0.006178)
Bit pos.		Description		37	Ni120 rtd (a=0.006720)
)2	0	baud rate = 4800 bit/s		38	voltage standard
	1	baud rate = 9600 bit/s		39	voltage extended
	2	baud rate = 19200 bit/s		40 41	resistance standard
	3 4	baud rate = 38400 bit/s baud rate = 57600 bit/s		42	resistance extended potentiometer
	5	baud rate = 37000 bit/s		43	callendar Van Dusen
4 Modbus Format	-	5000 1000 110200 5100		44	custom sensor
4 Modbus Format Bit pos.		Description	*10 Input Burnout (
)1	0	parity none	Bit pos.		Description
	1	parity even	00	0	input burnout active
	2	parity odd		1	input burnout off
22	0	termination resistance off	*11 Cold Junction (Comper	nsation
	1	termination resistance on	Bit pos.		Description
33	0 1	32-bit endianness little	01	0	internal
E l	•	32-bit endianness big		1	fixed
5 Input-to-Output		nent Description		2	other sensor
3i t pos.)3	0	input1 temp	*12 Cold Junction I		external
, .	1	input2 temp	Bit pos.		Description
	2	mean input temp = (input1 temp + input2 temp)/2	00	0	cold junction measured
	3	input1 temp - input2 temp	••	i 1	cold junction fixed
	4	input2 temp - input1 temp	*13 Alarm Configur	ation	
	5	max(input1 temp, input2 temp)	Bit pos.		Description
	6	min(input1 temp, input2 temp)	02	0	no alarm
	7 of the l	input redundancy = mean input temperature or temperature healthy sensor		1	alarm low
	8	electrical measure 1		2	alarm high
				3	alarm window
	9	electrical measure 2			fault repeater
		electrical measure 2 electrical measure + cj voltage 1 (compensated sensor 1)	*44.41	4	
	9		*14 Alarm Lock	·	·
6 Integration Spe	9 10 11 ed	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2)	Bit pos.	Value	Description
Bit pos.	9 10 11 ed Value	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description		Value 0	Description no alarm lock
	9 10 11 ed Value 0	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow	Bit pos. 00	Value 0 1	Description no alarm lock alarm lock activated
Bit pos. 00	9 10 11 ed Value	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description	Bit pos. 00 *15 Contact Position	Value 0 1 n In Ca	Description no alarm lock alarm lock activated se Of Alarm
Bit pos. O0 7 Sensor Family	9 10 11 ed Value 0 1	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast	Bit pos. 00	Value 0 1 n In Ca	Description no alarm lock alarm lock activated
3it pos. 3it pos. 7 Sensor Family 3it pos.	9 10 11 ed Value 0 1	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description	Bit pos. 00 *15 Contact Position Bit pos.	Value 0 1 n In Ca Value	Description no alarm lock alarm lock activated se Of Alarm Description
Bit pos. O0 7 Sensor Family	9 10 11 ed Value 0 1 Value 0	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple	Bit pos. 00 *15 Contact Positic Bit pos. 00	Value 0 1 n In Ca Value 0 1	Description no alarm lock alarm lock activated se Of Alarm Description open closed
3it pos. 3it pos. 7 Sensor Family 3it pos.	9 10 11 ed Value 0 1 Value 0 1	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd	Bit pos. 00 *15 Contact Position Bit pos.	Value 0 1 n In Ca Value 0 1	Description no alarm lock alarm lock activated se Of Alarm Description open closed
3it pos. 3it pos. 7 Sensor Family 3it pos.	9 10 11 ed Value 0 1 Value 0 1	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co	Value 0 1 n In Ca Value 0 1 nfigurat Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion
3it pos. 3it pos. 7 Sensor Family 3it pos.	9 10 11 ed Value 0 1 Value 0 1	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance	Bit pos. 00 *15 Contact Position Bit pos. 00 *16 Alarm Fault Co Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before faul
7 Sensor Family Bit pos.	9 10 11 ed Value 0 1 Value 0 1 2 3 4	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage	Bit pos. 00 *15 Contact Position Bit pos. 00 *16 Alarm Fault Co Bit pos.	Value 0 1 n In Ca Value 0 1 mfigurat Value 0 1 2	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm on in case of fault
3it pos. 3it pos. 7 Sensor Family 3it pos.	9 10 11 ed Value 0 1 Value 0 1 2 3 4	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01	Value 0 1 n In Ca Value 0 1 frigurat Value 0 1 2 3	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before faul
Bit pos. 3.0 7 Sensor Family Bit pos. 3.2 8 Sensor Connec	9 10 11 ed Value 0 1 Value 0 1 2 3 4	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm on in case of fault
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos.	9 10 11 ed Value 0 1 Value 0 1 2 3 4 tion Value	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm on in case of fault alarm off in case of fault
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos.	9 10 11 ed Value 0 1 2 3 4 tion Value 0	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos.	9 10 11 ed Value 0 1 2 3 4 tion Value 0 1 2 3 4 2 3 4	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 3 wires	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm on in case of fault alarm off in case of fault
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos.	9 10 11 ed Value 0 1 2 3 4 tion Value 0 1 2 3 4	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 3 wires res/rtd 4 wires	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos. 32	9 10 11 ed Value 0 1 2 3 4 tion Value 0 1 2 3 4 2 3 4	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 3 wires	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connect Bit pos. 32	9 10 11 ed Value 0 1 Value 0 1 2 3 4 tion Value 0 1 2 3 4 5	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 3 wires res/rtd 4 wires potentiometer 3 wires	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos. 32 9 Sensor Type Bit pos.	9 10 11 ed Value 0 1 Value 0 1 2 3 4 tion Value 0 1 2 3 4 ttion Value	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 4 wires potentiometer 3 wires Description	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connect Bit pos. 32	9 10 11 ed Value 0 1 Value 0 1 2 3 4 4 tion Value 0 1 2 3 4 4 to 0 1 2 3 4 5 5 5 7 8 9 9 1 9 1 9 1 9 1 9 1 9 1 9 1 9 1 9 1	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 4 wires potentiometer 3 wires Description thermocouple A1	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off
Bit pos. 30 7 Sensor Family Bit pos. 32 8 Sensor Connec Bit pos. 32 9 Sensor Type Bit pos.	9 10 11 ed Value 0 1 Value 0 1 2 3 4 tion Value 0 1 2 3 4 ttion Value	electrical measure + cj voltage 1 (compensated sensor 1) electrical measure + cj voltage 2 (compensated sensor 2) Description slow fast Description thermocouple rtd voltage resistance potentiometer Description volt/tc 2 wires tc + external compensation res/rtd 2 wires res/rtd 4 wires potentiometer 3 wires Description	Bit pos. 00 *15 Contact Positic Bit pos. 00 *16 Alarm Fault Co Bit pos. 01 *17 Alarm Virtual S Bit pos.	Value 0 1 n In Ca Value 0 1 nfigurat Value 0 1 2 3 tate Value 0	Description no alarm lock alarm lock activated se Of Alarm Description open closed tion Description ignore fault lock alarm state before fault alarm off in case of fault Description alarm off