



## **Characteristics:**

## General description:

This Termination Board (TB) provides direct connection between the I/O Card of the system and D5000 Series modules. The Intrinsically Safe protection and signal isolation between Safe and Hazardous Area is provided by D5000 Series Associated Apparatus. The 24 Vdc Power Supply of the TB is connected to two plug-in terminal blocks, for a redundant power supply. The power supply for modules is given by TB power bus.

## Termination Board general characteristics:

Termination Board Model	Number of positions	Features
TB-D5008- YOK-001	8	<ol> <li>I/O Card redundancy;</li> <li>Power Supply voltage redundancy;</li> <li>Abnormal supply voltage signaling;</li> <li>Cumulative module fault signaling.</li> </ol>

## Supported Yokogawa Prosafe RS I/O Cards:

I/O Card Model	l/O Card Type	Number of channels per I/O Card	Number of I/O Cards per board	Number of channels per board	Supported GM Modules
SDV531	Digital Out	8	1+(1)*	8	D5040S, D5048S, D5049S D5090S, D5091S.

\* with possibility of I/O Card redundancy.

# Termination Board 8 positions for Yokogawa Prosafe RS with Digital Output card SDV531

## **Technical Data:**

#### Supply:

- 24 Vdc nom (20 to 30 Vdc) reverse polarity protected, double terminal blocks for redundant power supply, with OR diodes to mix supply voltages. **Connection:** by polarized plug-in disconnect screw terminal blocks to accommodate
- terminations up to 2.5 mm<sup>2</sup>.
- **Protection fuse:** 2 A slow blow (spare fuse provided on Termination Board). **Fault detection:** (for more information see Fault Logic section)

Abnormal supply voltages or module cumulative fault: PWR 1 or PWR 2 is in under (< 18 Vdc) or over (> 30 Vdc) voltage condition <u>OR</u> module cumulative fault indication.

**Relay fault signaling:** a voltage free NE SPST-1 Form A relay contact (de-energized in fault condition), with the following characteristics:

Contact material: AgCdO.

Contact rating: 2 A 36 Vac 72 VA, 2 A 48 Vdc 80 W (resistive load).

Mechanical / Electrical life: 30 \* 10<sup>6</sup> / 1 \* 10<sup>5</sup> operation, typical.

Connection: by polarized plug-in disconnect screw terminal blocks to accommodate terminations up to 2.5 mm<sup>2</sup>.

- LED fault signaling: 1 green LED (PWR 1 OK); 1 green LED (PWR 2 OK);
- 1 red LED (UV or OV of PWR 1); 1 red LED (UV or OV of PWR 2);

### a cumulative fault red LED.

### Prosafe RS I/O card interface:

Connection: two 50 poles male connectors (require female mating connectors). Field signal:

Connection: directly to module by polarized plug-in disconnect screw terminal blocks to accommodate terminations up to 2.5 mm<sup>2</sup>.

Environmental conditions:

Operating: temperature limits – 40 to + 70 °C,

relative humidity max 90 % non condensing, up to 35 °C.

Storage: temperature limits - 45 to + 80 °C.

#### Mounting:

Hardware included for mounting on wall and single DIN rail.


Weight: about 200 g (excluding modules).

Location: Safe Area / Ordinary locations.

Dimensions: Width 165 mm, Depth 176 mm, Height 125 mm.


## Features:

- DO card type SDV 531 (8 channels) Digital Output board interface.
- 8 positions Terminal Board for up to 8 channels.
- Lower cables installation and maintenance costs.
- Power supplies fault monitoring.
- Spare fuse provided.
- Mounting hardware provided for:
  - Single Din Rail mounting kit.
  - Wall mounting, M4 self tapping screw; Wall mounting, M4 thread screw;




## **Ordering Information:**

Model: TB-D5008-YOK-001



G.M. International DTS0405-4 Page 2/15




G.M. International DTS0405-4 Page 3/15


# Loop Diagrams for Prosafe RS SDV531 (8 DO) Interface Card:

SAFE AREA

#### Note:


Model D5090S and D5091S SIL3 Relays do not have Intrinsically safe outputs and therefore must not be placed on same board with D5040S, D5048S and D5049S.






LED Signaling: Meaning of LEDs on termination boards:


TAG	LED COLOR	MEANING		
PWR 1 OK	GREEN	The LED is on when PWR 1 is within the regular range (>18 V and <30 V).		
PWR 1 Over or Under V	RED	The LED is on when PWR 1 is in over-voltage (>30V) or under-voltage (<18 V).		
PWR 2 OK	GREEN	The LED is on when PWR 2 is within the regular range $$ (>18 V and <30 V).		
PWR 2 Over or Under V	RED	The LED is on when PWR 2 is in over-voltage (>30V) or under-voltage (<18 V).		
Cumulative Fault		The LED is on when at least one module / barrier reported a fault.		




Relay Activation Conditions: The two relays are activated according to the following rules:


TAG	ACTIVATION			
ALARM	<ol> <li>The relay is energized when the following two conditions hold:</li> <li>both supply voltages are within the regular range (&gt;18 V and &lt;30 V).</li> <li>No module / barrier fault is reported.</li> </ol>			






## DIN Rail mounting overall dimensions:






G.M. International DTS0405-4 Page 8/15


Mounting features kit TB-OPT-001




T35 DIN Rail


Ref. Nr	Q.ty	Description	Material
1	2	T35 Din Rail Adapter	PA
2	6	3.5 x 9.5 Self tapping screw	Stainless Steel
3	6	M3 External Tooth loch Washer	Stainless Steel
4	6	M3 Washer	Stainless Steel
5	2	6 c 20 Spacer	PA






Mounting features kit TB-OPT-001







Ref. Nr	Q.ty	Description	Material
6	4	M4 x 8 Screw	Stainless Steel
7	4	M4 External Tooth lock Washer	Stainless Steel
8	8	M4 Washer	Stainless Steel
9	4	Self Tapping Spacer	NI - Plated Brass

## Wall mounting overall dimensions for M4 thread screw:







Ref. Nr	Q.ty	Description	Material
10	4	M4 x 8 Screw	Stainless Steel
11	8	M4 External Tooth lock Washer	Stainless Steel
12	8	M4 Washer	Stainless Steel
13	4	Threaded Spacer	NI - Plated Brass
14	4	M4 Nut	Stainless Steel

# Connections table to Interface Card:

FIELD DEVICE	MODULE TYPE	MODULE FUNCTION	MODULE POSITION	INTERFACE CARD CHANNEL NUMBER	INTERFACE CARD CONNECTOR PIN NUMBER	INTERFACE CARD REDUNDANT CONNECTOR PIN NUMBER	NOTE
			1	1	(+) 48 (CN1) (-) 47 (CN1)	(+) 48 (CN2) (-) 47 (CN2)	
	D5040S, D5048S, D5049S D5090S, D5091S,		2	2	(+) 46 (CN1) (-) 45 (CN1)	(+) 46 (CN2) (-) 45 (CN2)	Interface Card Connectors CN1,     ON: 50 makes makes
			3	3	(+) 44 (CN1) (-) 43 (CN1)	(+) 44 (CN2) (-) 43 (CN2)	<ul> <li>CN2: 50 poles male.</li> <li>The poles No. 2, 3, 4, 5, 6, 7, 8, 10 are connected to +24 Vdc supply of TB.</li> <li>The poles No. 9, 11, 12, 13, 14, 15, 16, 49 are connected to GND of TB.</li> <li>The poles No. 1 and No. 50 are connected together.</li> <li>The poles from No. 17 to No. 32</li> </ul>
			4	4	(+) 42 (CN1) (-) 41 (CN1)	(+) 42 (CN2) (-) 41 (CN2)	
K K			5	5	(+) 40 (CN1) (-) 39 (CN1)	(+) 40 (CN2) (-) 39 (CN2)	
			6	6	(+) 38 (CN1) (-) 37 (CN1)	(+) 38 (CN2) (-) 37 (CN2)	
			7	7	(+) 36 (CN1) (-) 35 (CN1)	(+) 36 (CN2) (-) 35 (CN2)	
			8	8	(+) 34 (CN1) (-) 33 (CN1)	(+) 34 (CN2) (-) 33 (CN2)	are not connected because not used.

