



Characteristics:

General description:

This Termination Board (TB) provides direct connection between the I/O Card of the system and D5000 Series modules. The Intrinsically Safe protection and signal isolation between Safe and Hazardous Area is provided by D5000 Series Associated Apparatus. The 24 Vdc Power Supply of the TB is connected to two plug-in terminal blocks, for a redundant power supply. The power supply for modules is given by TB power bus.

Termination Board general characteristics:

Termination Board Model	Number of positions	Features
TB-D5016- YOK-009	16	 I/O Card redundancy; Power Supply voltage redundancy; Abnormal supply voltage signaling; Cumulative module fault signaling.

Supported Yokogawa Centum VP I/O Cards:

I/O Card Model	I/O Card Type	Number of channels per I/O Card	Number of I/O Cards per board	Number of channels per board	Supported GM Modules	
ADV551		32	1+(1)*			
ADV561	Digital Out	64	1/2+(1/2)**	32	D5040D	

* with possibility of I/O Card redundancy.

** with possibility of I/O Card redundancy.

Two TB-D5016-YOK-009 boards are necessary to provide 64 channels to I/O card (32 channels each)

Features:

- DO card type ADV551 (32 channels) Digital Output board interface.
- DO card type ADV561 (64 channels) Digital Output board interface.
- 16 positions Terminal Board for up to 32 channels.
- Lower cables installation and maintenance costs.
- Power supplies fault monitoring.
- Spare fuse provided.
- Mounting hardware provided for: Single Din Rail mounting kit; Wall mounting, M4 self tapping screw; Wall mounting, M4 thread screw.

Termination Board 16 positions for Yokogawa Centum VP with Digital Output cards ADV551, ADV561

Technical Data:

Supply:

- 24 Vdc nom (20 to 30 Vdc) reverse polarity protected, double terminal blocks for redundant power supply, with OR diodes to mix supply voltages. Connection: by polarized plug-in disconnect screw terminal blocks to accommodate
- terminations up to 2.5 mm².
- *Protection fuse:* 4 A slow blow (spare fuse provided on Termination Board). **Fault detection:** (for more information see Fault Logic section)

Abnormal supply voltages <u>or</u> module cumulative fault: PWR 1 or PWR 2 is in under (< 18 Vdc) or over (> 30 Vdc) voltage condition <u>OR</u> module cumulative fault indication.

Relay fault signaling: a voltage free NE SPST-1 Form A relay contact (de-energized in fault condition), with the following characteristics:

Contact material: AgCdO.

Contact rating: 2 A 36 Vac 72 VA, 2 A 48 Vdc 80 W (resistive load).

Mechanical / Electrical life: 30 * 106 / 1 * 105 operation, typical.

Connection: by polarized plug-in disconnect screw terminal blocks to accommodate terminations up to 2.5 mm².

- LED fault signaling: 1 green LED (PWR 1 OK); 1 green LED (PWR 2 OK);
- 1 red LED (UV or OV of PWR 1); 1 red LED (UV or OV of PWR 2);

a cumulative fault red LED.

Centum VP I/O card interface:

Connection: two 50 poles male connectors (require female mating connectors). Field signal:

Connection: directly to module by polarized plug-in disconnect screw terminal blocks to accommodate terminations up to 2.5 mm².

Environmental conditions:

Operating: temperature limits - 40 to + 70 °C,

relative humidity max 90 % non condensing, up to 35 °C.

Storage: temperature limits - 45 to + 80 °C.

Mounting:


Hardware included for mounting on wall and single DIN rail.

Weight: about 400 g (excluding modules and mounting options).

Location: Safe Area / Ordinary locations.

Dimensions: Width 267 mm, Depth 176 mm, Height 125 mm.


Image:





Ordering Information:

Model: TB-D5016-YOK-009

G.M. International DTS0579-3 Page 1/15









LED Signaling: Meaning of LEDs on termination boards:

TAG	LED COLOR	MEANING		
PWR 1 OK	GREEN	The LED is on when PWR 1 is within the regular range $(>18 \text{ V and } <30 \text{ V})$.		
PWR 1 Over or Under V	RED	The LED is on when PWR 1 is in over-voltage (>30V) or under-voltage (<18 V).		
PWR 2 OK	GREEN	The LED is on when PWR 2 is within the regular range $(>18 \text{ V and } <30 \text{ V})$.		
PWR 2 Over or Under V	RED	The LED is on when PWR 2 is in over-voltage (>30V) or under-voltage (<18 V).		
Cumulative Fault	RED	The LED is on when at least one module / barrier reported a fault.		




Relay Activation Conditions: The two relays are activated according to the following rules:


TAG	ACTIVATION
ALARM	 The relay is energized when the following two conditions hold: both supply voltages are within the regular range (>18 V and <30 V). No module / barrier fault is reported.




SAFE AREA / ORDINARY LOCATION




HAZARDOUS AREA / LOCATION




G.M. International DTS0579-2 Page 7/15






Mounting features kit TB-OPT-001




Ref. Nr	Q.ty	Description	Material
1	2	T35 Din Rail Adapter	PA
2	6	3.5 x 9.5 Self tapping screw	Stainless Steel
3	6	M3 External Tooth loch Washer	Stainless Steel
4	6	M3 Washer	Stainless Steel
5	2	6 c 20 Spacer	PA

T35 DIN Rail

Wall mounting overall dimensions for M4 self tapping screw:









Ref. Nr	Q.ty	Description	Material
6	4	M4 x 8 Screw	Stainless Steel
7	4	M4 External Tooth lock Washer	Stainless Steel
8	8	M4 Washer	Stainless Steel
9	4	Self Tapping Spacer	NI - Plated Brass

Wall mounting overall dimensions for M4 thread screw:







Ref. Nr	Q.ty	Description	Material
10	4	M4 x 8 Screw	Stainless Steel
11	8	M4 External Tooth lock Washer	Stainless Steel
12	8	M4 Washer	Stainless Steel
13	4	Threaded Spacer	NI - Plated Brass
14	4	M4 Nut	Stainless Steel

FIELD DEVICE	MODULE TYPE	MODULE FUNCTION	MODULE POSITION	MODULE CHANNEL NUMBER ("B" is only for double channel)	INTERFACE CARD CHANNEL NUMBER	INTERFACE CARD CONNECTOR PIN NUMBER	INTERFACE CARD REDUNDANT CONNECTOR PIN NUMBER	NOTE
			1	1A	1	(-) 50 (CN1)	(-) 50 (CN2)	
			2	2A	2	(-) 48 (CN1)	(-) 48 (CN2)	
			3	3A	3	(-) 46 (CN1)	(-) 46 (CN2)	
			4	4A	4	(-) 44 (CN1)	(-) 44 (CN2)	
			5	5A	5	(-) 42 (CN1)	(-) 42 (CN2)	1
			6	6A	6	(-) 40 (CN1)	(-) 40 (CN2)	
			7	7A	7	(-) 38 (CN1)	(-) 38 (CN2)	
			8	8A	8	(-) 36 (CN1)	(-) 36 (CN2)	 Interface Card Connectors
			9	9A	9	(-) 34 (CN1)	(-) 34 (CN2)	CN1, CN2: 50 poles male.
			10	10A	10	(-) 32 (CN1)	(-) 32 (CN2)	For Interface Card channel
			11	11A	11	(-) 30 (CN1)	(-) 30 (CN2)	number 1 to 16, the poles
	D5040D (Double channel)		12	12A	12	(-) 28 (CN1)	(-) 28 (CN2)	No. 12, 14, 16, 18 are
		Digital Output	13	13A	13	(-) 26 (CN1)	(-) 26 (CN2)	Common poles connected to GND of TB, while the poles No. 8 and 10 are Common poles connected to +24 Vdc supply of TB. For Interface Card channel number 17 to 32, the poles No. 11, 13, 15, 17 are Common poles connected
			14	14A	14	(-) 24 (CN1)	(-) 24 (CN2)	
			15	15A	15	(-) 22 (CN1)	(-) 22 (CN2)	
			16	16A	16	(-) 20 (CN1)	(-) 20 (CN2)	
M			1	1B	17	(-) 49 (CN1)	(-) 49 (CN2)	
			2	2B	18	(-) 47 (CN1)	(-) 47 (CN2)	
			3	3B	19	(-) 45 (CN1)	(-) 45 (CN2)	
			4	4B	20	(-) 43 (CN1)	(-) 43 (CN2)	
			5	5B	21	(-) 41 (CN1)	(-) 41 (CN2)	to GND of TB, while the
			6	6B	22	(-) 39 (CN1)	(-) 39 (CN2)	poles No. 7 and 9 are
			7	7B	23	(-) 37 (CN1)	(-) 37 (CN2)	Common poles connected
			8	8B	24	(-) 35 (CN1)	(-) 35 (CN2)	to +24 Vdc supply of TB.
			9	9B	25	(-) 33 (CN1)	(-) 33 (CN2)	The poles from No. 3 to No. 6 are not connected because not used. The poles No. 1 and No. 2 are connected together.
			10	10B	26	(-) 31 (CN1)	(-) 31 (CN2)	
			11	11B	27	(-) 29 (CN1)	(-) 29 (CN2)	
			12	12B	28	(-) 27 (CN1)	(-) 27 (CN2)	
			13	13B	29	(-) 25 (CN1)	(-) 25 (CN2)	 For each channel, the
			14	14B	30	(-) 23 (CN1)	(-) 23 (CN2)	positive pole of signal is connected to +24 Vdc
			15	15B	31	(-) 21 (CN1)	(-) 21 (CN2)	
			16	16B	32	(-) 19 (CN1)	(-) 19 (CN2)	supply of TB.

Connections table to Interface Card:

